

Afterglow Ignite Wired Controller

Quick Setup Guide

Package Contents


Afterglow™ Ignite Wired Controller

10ft / 3m USB-C Cable

Quick-Start Insert


1. Initial Setup

Plug the USB-C end of the cable into the top of the controller, and the USB side into your console or PC. Press the Xbox button, and once the Xbox button starts to illuminate, the controller is connected and ready to use.




2. Mute Microphone

Press the function button twice to mute your microphone.




3. Control Volume

While holding down the function button, press D-Pad +Up/-Down to adjust game volume.



4. Game/Chat Balance


While holding down the function button, press D-Pad Left/Right to adjust game/chat balance.



5. Program Back Buttons


A. While holding down the function button, press the back button you would like to map a function to, and the function button LED will start flashing.

B. Press any button you would like mapped, and the function button LED will flash 3 times indicating a successfully mapped function.



6. Hair-Trigger Mode

Hair-trigger feature is a highly sought-after feature that allows faster trigger pulls and adds advantages to your gaming experience. Afterglow Ignite Wired Controller uses Hall switch true digital hair-triggers for a rapid and precise trigger response.



To enable hair trigger mode

- A. Toggle the slider buttons on the back of the controller upward to set the trigger buttons to hair-trigger mode.
- B. Toggle the slider buttons on the back of the controller downward to set the trigger buttons back to full-distance mode.

7. Changing the Lighting Effects

A. To cycle through the lighting effects, hold down the function button and press either the L or R buttons.


B. Lighting Effects:

Static: The RGB lights will remain solid and set to a chosen color.

Wave: Displays a rainbow of RGB lights in a continuous motion.

Breathing: The RGB lights slowly fade in and out on a set color.


Rumble: The in-game rumble will activate a set color for the RGB lights.



Go to the Control Hub app for advanced settings for the lighting effects.

8. Adjust Lighting


- A. Hold down the function button and use the left analog stick to change the LED color.
- B. Once you find the color you'd like, save the setting by releasing the function button.
- C. For white, hold down the function button and click in the left stick.
- D. To adjust the brightness, hold down the function button and press the left trigger.



Go to the Control Hub app for advanced settings for the lighting effects.

9. Changing the Settings for the RGB Zones

The Afterglow Ignite Wired Controller comes with different RGB Zones that can be customized individually or multiple at once on the Control Hub app.



10. Control Hub

To customize your controller further, download the free Control Hub App from the Windows Store on your PC or Xbox. You can use it to re-map buttons, run diagnostics, recalibrate analog sticks and triggers, and much more.

How to download: Open the Microsoft Store from your PC or Xbox console, search and download "Turtle Beach-PDP Control Hub". Or, if you are on PC, download the App from this

link: <https://apps.microsoft.com/detail/9p3l4zvw8vdf>

Afterglow Ignite Wired Controller - Customize RGB

Using the [Turtle Beach - PDP Control Hub App](#), you can customize the controller's RGB Lightning Effects.

Lightning Effect Profiles

The controller has four RGB profiles that you can use to customize settings, for each profile, you can edit specific RGB Zones by selecting the option below the controller, the controller has 7 RGB Lights that can be customized on each profile for different effects, depending on the Lightning effect.

Profile Settings

You can also customize the Profile by changing the Lightning effect, speed, Brightness, Color, Loop and Activate with:

- Lightning effect: You can choose between Static, Wave, Breathing, Rumble, Pulse, Ripple, Upflow, Downflow.
- Speed: Select the speed of the Lightning effect in the profile.
- Brightness: Select the brightness of the Lightning effect in the profile.
- Color: Select a specific color for the profile.
- Loop: Select to loop the Lightning effect in the profile.
- Activate with: You can choose between activating the Lightning profile with Timer, Left motor, Right motor, Any motor, Left speaker, Right speaker, Mic.

Afterglow Ignite Wired Controller - Frequently Asked Questions

- **Is this controller wireless and does it use batteries?**
 - This controller is wired, it doesn't have wireless capability, this means it doesn't use batteries.
- **Can you use any wire with this controller?**
 - We recommend using the provided USB-C cable, in case this cable has been misplaced, you are able to use high speed USB-C cables to power your controller.
- **Is the controller plug and play?**
 - Yes, the controller is plug-and-play, we also recommend downloading the [Turtle Beach - PDP Control Hub App](#) from the Microsoft store to make sure your controller has the latest firmware.
- **Is the controller Officially Licensed?**
 - Yes, the controller is Officially Licensed by Microsoft.
- **Is the controller compatible with Nintendo Switch™, Mac, Chromebook or mobile devices?**
 - No, the controller is designed for Xbox Series X/S, Xbox One and Windows 10/11.
- **Can I use the controller without downloading the [Turtle Beach - PDP Control Hub App](#)?**
 - You can use it without downloading the app, but console updates, as well as general usage, may cause common issues like drifting and those can be fixed by updating the app.
- **Can I modify the components of the controller?**
 - Unauthorized modification or repair of the controller will result in voiding the warranty, if you're experiencing issues with a button or function, please contact our technical support team and we'll be glad to assist you.
- **How can I configure the features on the controller?**
 - You can adjust features through the [Turtle Beach - PDP Control Hub App](#). *As a note, you can map the front-facing buttons to the back paddles, but you can't map triggers or keyboard keys to the back paddles.*
- **How do I adjust the hair triggers?**
 - To enable hair trigger mode: Toggle the slider buttons on the back of the controller upward to set the trigger buttons to hair-trigger mode. Toggle the slider buttons on the back of the controller downward to set the trigger buttons back to full-distance mode

Afterglow Ignite Wired Controller - Technical Specifications

- **Wired/Wireless**
 - Wired
- **Cord Length (m/ft)**
 - 3/10
- **Headset Jack**
 - Yes. 3.5mm jack (CTIA)

- **Compatibility**
 - Xbox Series S|X, Xbox One and Windows 10/11
- **Color**
 - Clear
- **Stick Type**
 - Potentiometer
- **Button Mapping**
 - Yes. 2 back Buttons.
- **Audio Controls**
 - Game Volume, Chat Mix, Mic Monitoring, Mic Mute(double click Function button)
- **Rumble Vibration**
 - Yes
- **Impulse Triggers**
 - Yes
- **Trigger type**
 - Hall effect digital trigger
- **Hair triggers**
 - Yes
- **Trigger Stop**
 - 2 stop
- **Lighting Type**
 - 7 lighting zones, 4 Preset lighting modes on the controller, more to download in the control hub app
- **Firmware Updateable**
 - Yes

Product Measurements

- **Weight (g/lb)**
 - 201/0.44
- **Width (mm/inches)**
 - 155/6.1
- **Height (mm/inches)**
 - 104/4.09
- **Depth (mm/inches)**
 - 65/2.56