
Yaber
PROJECTOR



Quick Start Guide

Yaber **L3**

EN

Contents

English	01
Deutsch	08
Français	15
Italiano	22
Español	29
日本語	36
Русский	43
繁体中文	50

Dear Valued Customer,
Thank you for choosing the Yaber **L3 Projector**. Please read the Quick Start Guide (QSG) carefully before using your Yaber L3 Projector. **Scan the QR code on the next page to get detailed product user manual and video guideline**. We encourage you to explore them in depth.

We understand that you may encounter various questions and issues while using the projector. However, leaving a review on the product page will not help improve your experience. (Please let us help you! We truly appreciate your feedback and will promptly provide a satisfying solution.)

If you encounter any issues, feel free to send your order number and the problems to us at **global@yaber.com. (Title: US+L3+000-0000000-0000000+Issues)** Rest assured, our service team will offer the solution to you within 24 hours.

Your satisfaction is our top priority. If you encounter any problems, we sincerely hope that you will give us the opportunity to resolve them. We are dedicated to offering you the best possible solution. We appreciate your understanding and patience in advance.

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Scan the QR Code to Watch the Tutorial

PDF User Manual

Scan and download

Video Guideline


Scan to learn more


FAQ


global@yaber.com


www.yaber.com @yaberofficia @yaber.projecto


Product Overview














QSG




Power Cord



Cleaning Kits

Projection Distance & Size




Meters	3.6ft	5.4ft	6.8ft	7.2ft	9.0ft	10.8ft	13.5ft
Feet	1.10m	1.65m	2.07m	2.20m	2.75m	3.29m	4.12m

The recommend projection distance is about **9.0ft/ 2.75m.**

Adjust Screen Display

1. Keystone Correction and Focus Adjustment







1) L3 supports "Large Angle Side Projection", which means users can still have a clear image even if the projector is not perpendicular to the screen. For projection quality, please ensure that the projector's tilt angle does not exeed 30°(Horizontally) and 25° (Vertically),or the automatic adjustment may not work properly.

2) Select the **[Projector]** menu. Turn on **[Auto Keystone After Boot/Upon Motion]** and **[Auto Focus After Boot/Upon Motion]** function, then it will automatically focus and adjust keystone every time you move the projector or turn it on.

3) If the image remains blurry, adjust the focus buttons **"F+"** and **"F-"** on the projector remote control to fine-tune the image clarity.

2. Auto Screen Fit and Auto Obstacle Avoidance





When the **[Obstacle Avoidance on Keystone]** is enabled, the image will automatically avoid obstacles if there are obstacles in the projection area. When the **[Screen Alignment on Keystone]** is enabled, the image will automatically match the screen if there is a **16:9** in the projection area.

3. Picture and Sound Adjustment

In **[Settings]-[Projector]-[Projector Light Mode]**, users can set between 3 Modes:

1) ECO Mode: Lower brightness for lower power consumption.

2) Standard: Default, bright image with low noise.

3) High Performance: Best bright level.

Note: High Performance mode may have louder noise.

Wireless Connection & Smart Features

1. WiFi Setting

Select the **[Connection]** menu -- **[Network]**. Enable the **[Network Connection]** option. Choose the network and type the password that you want to connect to.

Attention: The fluency of casting & sharing with a wireless connection will be affected by the network environment. Content Sharing allows you to view media content like videos, music and photos saved in your Android/iOS/PC device on your screen. Please ensure that **[Content Sharing]** is enabled in the **[Multimedia Device Connection]** before sharing.

2. Ways to Access More Apps

1) Only pre-installed apps listed in the **[App Store]** are available for download.

2) Please note that the projector does not support downloading apps via a web browser or APK file. However, if the streaming app you are looking for has a web version, you can watch it directly through the built-in browser, or access the unsupported app using a TV stick (sold separately). If you cannot find the app you need or encounter any playback issues, please feel free to contact us.

3) The L3 is compatible with Roku, Fire TV Stick, and other major streaming devices. To use a TV stick, connect it to the projector via the HDMI port and power it via the projector's USB port or an external power adapter.

3. For iOS System (AirPlay)



Living Room Device


Attention: Ensure that your iOS device is connected to the same Wi-Fi network as your projector.

1) Connect the projector to your home Wi-Fi.


2) Back to home page -- Press the ⏎ on the remote control -- Select [AirPlay] -- Stay on this interface.


3) Access the **[Control Center]** on your iOS device -- Select the **[Screen Mirroring]** function -- Select and connect the console name **[Living Room Device]**. If an AirPlay passcode appears on the screen, enter the passcode on your Apple device to continue.


4. For Android and Windows 10+ OS (Screen Sharing)











Attention: Android devices may use various terms and methods to enable screen mirroring. Ensure that your Android device is connected to the same Wi-Fi network as your projector.

1) Back to home page -- Press the on the remote control -- Select**[Screen Sharing]** -- Stay on this interface.

2) Access the **[Control Center]** on your Android device, select **[Screen Mirroring/Smart View].**

3) Select and connect the console name **[Living Room Device]**.